

How To Install Your 10W, 20W, or 30W Solar Panel

Step 1:

Turn your solar panel face down & line the bracket along the center with the bracket's connector end positioned upward & hanging off the panel's edge.



Step 2:

Screw the bracket onto the solar panel using the 1/2" self-tapping tek screws, which are included with the bracket.



Step 3:

If you need additional wire, use wire nuts to tie the red ends together & the black ends together.



Step 4:

Attach the solar panel to the surface of your choice using the remaining self-tapping screws.

